

mini_Eggshell

MAS T1 | 28.10.2019

Content

Introduction

Eggshell


Previous Miniprojects

Assignment

Schedule


Ur online control

Introduction




Paulo, Monteiro, Sabbie, Miller and Horvath (2017)

Cost of a standard concrete element



Lab (2007)

Cost of a non-standard concrete element




Schipper and Grünewald (2014)



MuCEM Marseille - Rudy Ricciotti (2013)
<https://generationvoyage.fr/visiter-mucem/>




Gramazio Kohler Research
ETH Zurich



best of DETAIL 8 Beton/Concrete, Christian Schittich (2016)


Eggshell concept



Ulrich (2017)



Simultaneous printing & filling




Consecutive fabrication




Consecutive fabrication



Consecutive fabrication



Basler & Hofmann



Gramazio Kohler Research
ETH Zurich







minijammed

minijammed is a three-week design and build assignment based on the ongoing research project Jammed Architectural Structures. The research focuses on the development of design and fabrication techniques to build fully reversible architectural structures by interlacing crushed-rock stones with textile string without any permanent bonding. The potential of the concept has been proven at architectural scale through the realisation of larger prototypes: Rock Print and Rock Print: A Manistone. minijammed invites the students to explore the design possibilities and the rich solution space of the method in a smaller scale.

The short-term project suggests a material-driven design and a robotic fabrication strategy, as only through the execution of multiple physical experiments, both manual and robotic, the designer is able to take informed decisions about the final outcome of the process.

minijammed: final exhibition





Gramazio Kohler Research
ETH Zurich



Okawa, Ruangjun, Jeong, 2017





Pastrana, Su, Lin, Yoo, 2017



Gramazio Kohler Research
ETH Zurich



Taha, Mitropolou, 2017





Cena, Chousou, Wang, Wu, 2017


Rapid Clay Formations

Rapid Clay Formations is a four-week design and build assignment investigating a novel fabrication process for malleable materials. Starting with the Remote Material Deposition installation in 2014, the Chair of Architecture and Digital Fabrication has investigated the idea of robotically positioning material in space from a distance and thereby creating differentiated architectural aggregations that are a direct expression of a dynamic and adaptive fabrication process. Continuing this concept, more recent projects developed within the MAS programme shifted the focus to the study of robotic fabrication processes for malleable materials, where the precise control of forces and positions applied to the material to design and build highly differentiated structures.

Rapid Clay Formations: final presentation



Rapid Clay Formations: double-bullet tool





Akizuki, Barney, Du, 2018





mini-eggshell: Assignment

Use the Eggshell simultaneous printing & filling process to produce various building components.

Two formwork material options

- Clay - 3 setups
- Thermoplastic - 3 setups

Different building elements

- Beam
- Slab
- Wall
- Interface element (column - beam or wall - slab)
- Column

mini-eggshell: Goals

Focus on:

- Structure (reduce material/ weight, precise guides for reinforcement)
- Function (integrate different functions, lighting , media, electrical or mechanical services)
- Performance (integrate natural lighting and ventilation through transparency, porosity. Acoustics)
- Aesthetics (surface textures and ornamentation, architectural design, details)



3D-printed floor system, Block Research Group



Topology optimisation, Asbjørn Søndergaard / Odico Formwork Robotics



DIGITAL GROTESQUE II, Benjamin Dillenburger and Michael Hansmeyer



Elbphilharmonie, HdM

Schedule


<https://docs.google.com/spreadsheets/d/181aZo1s0SwAvfoG4fKHYC5BHTWoBZZNCnyvJNnxfnJw/edit?usp=sharing>

Guest Lectures

Dr. Lex Reiter (post-doc in PCBM)



Lukas Gebhard (PhD student with IBK)




Dr. Thibault Demoulin (post-doc at PCBM and Oxara)



[illegible]







- Gramazio Kohler Research**
ETH Zurich

86



Settings (ip address, robot, tool)

Calculate Basis



Design

Commands generation and JSON

Visualization


Direct Control




0b






Direct UR control



Calculate basis







main_direct_send_group_00.py X

```

C:\Users\ricta> Downloads > main_direct_send_group_00.py > (5) main
1  from __future__ import print_function
2  from __future__ import absolute_import
3
4  import time
5  import sys
6  import os
7  import json
8
9  import socket
10
11  UR_SERVER_PORT = 30002
12
13  # python C:\Users\ricta\Documents\Projects\WSL\cayur_online_control\communication\main_direct_send_cay.py
14  # set the paths to find library
15  file_dir = os.path.dirname(__file__)
16  parent_dir = os.path.abspath(os.path.join(file_dir, "..", ".."))
17  sys.path.append(file_dir)
18  sys.path.append(parent_dir)
19
20  from ur_online_control.communication.formatting import format_commands
21  ....
22
23  # GLOBALS
24  # =====
25  server_address = "192.168.10.11"
26  server_port = 30001
27  ur_ip = "192.168.10.10"
28  tool_angle_axis = [-0.7915, -1.0705, 264.9818, 3.1415, 0.0, 0.0]
29  # =====
30
31  # COMMANDS
32  # =====
33  path = os.path.dirname(os.path.join(__file__))
34  filename = os.path.join(path, "..", "commands.json")
35  with open(filename, 'r') as f:
36      data = json.load(f)
37
38  # load the commands from the json dictionary
39  move_filament_loading_pt = data['move_filament_loading_pt']
40  lee_command = data['lee_command']
41  gh_commands = data['gh_commands']
42  commands = format_commands(gh_commands, lee_command)
43  print("we have %d commands to send" % len(commands))
44  # =====
45
46  # UR SCRIPT
47  # =====
48  > def move_commands(server_address, port, tcp, commands): --
49
50
51  > def start_extruder(tcp, move_command, digital_output):
52
53
54  > def stop_extruder(tcp, move_command, digital_output): --
55
56
57
58  > def main(commands): --
59
60
61  if __name__ == "__main__":
62      main(commands)
63
64

```

```

1  # =====
2  # GLOBALS
3  # =====
4  server_address = "192.168.10.11"
5  server_port = 30001
6  ur_ip = "192.168.10.10"
7  tool_angle_axis = [-0.7915, -1.0705, 264.9818, 3.1415, 0.0, 0.0]
8  # =====
9
10 # COMMANDS
11 # =====
12 path = os.path.dirname(os.path.join(__file__))
13 filename = os.path.join(path, "..", "commands.json")
14 with open(filename, 'r') as f:
15     data = json.load(f)
16
17 # load the commands from the json dictionary
18 move_filament_loading_pt = data['move_filament_loading_pt']
19 lee_command = data['lee_command']
20 gh_commands = data['gh_commands']
21 commands = format_commands(gh_commands, lee_command)
22 print("we have %d commands to send" % len(commands))
23 # =====
24
25 # UR SCRIPT
26 # =====
27 > def move_commands(server_address, port, tcp, commands): --
28
29
30 > def start_extruder(tcp, move_command, digital_output):
31
32
33 > def stop_extruder(tcp, move_command, digital_output): --
34
35
36
37 > def main(commands): --
38
39
40 if __name__ == "__main__":
41     main(commands)
42
43

```



main_direct_send_group_00.py X

C: > Users > nizta > Downloads > main_direct_send_group_00.py > ...

```
1  from __future__ import print_function
2  from __future__ import absolute_import
3
4  import time
5  import sys
6  import os
7  import json
8
9  import socket
10
11  UR_SERVER_PORT = 30002
12
13  # python c:\Users\nizart\Documents\Projects\MAS_clay\ur_online_control\communication\main_direct_send_clay.py
14  # set the paths to find library
15  file_dir = os.path.dirname(__file__)
16  parent_dir = os.path.abspath(os.path.join(file_dir, "..", ".."))
17  sys.path.append(file_dir)
18  sys.path.append(parent_dir)
19
20  from ur_online_control.communication.formatting import format_commands
21
22  # GLOBALS
23  # =====
24  server_address = "192.168.10.11"
25  server_port = 30003
26  ur_ip = "192.168.10.10"
27  tool_angle_axis = [-68.7916, -1.0706, 264.9818, 3.1416, 0.0, 0.0]
28  # =====
29
30  # COMMANDS
31  # =====
32  path = os.path.dirname(os.path.join(__file__))
33  filename = os.path.join(path, "..", "commands.json")
34  with open(filename, 'r') as f:
35      data = json.load(f)
```


main_direct_send_group_00.py X

C:\> Users > nizta > Downloads > main_direct_send_group_00.py > ...

```
29
30 # COMMANDS
31 # =====
32 path = os.path.dirname(os.path.join(__file__))
33 filename = os.path.join(path, "..", "commands.json")
34 with open(filename, 'r') as f:
35     data = json.load(f)
36 # load the commands from the json dictionary
37 move_filament_loading_pt = data['move_filament_loading_pt']
38 len_command = data['len_command']
39 gh_commands = data['gh_commands']
40 commands = format_commands(gh_commands, len_command)
41 print("We have %d commands to send" % len(commands))
42 # =====
43
44 # UR SCRIPT
45 # =====
46 > def move_commands(server_address, port, tcp, commands):...
62
63 # =====
64 > def start_extruder(tcp, move_command, digital_output):...
77
78 # =====
79 > def stop_extruder(tcp, move_command, digital_output):...
92
93 # =====
94 > def main(commands):...
140
141
142 if __name__ == "__main__":
143     main(commands)
144
```

main_direct_send_group_00.py X

C:\> Users > nitzta > Downloads > main_direct_send_group_00.py > ...

```
43
44 # UR SCRIPT
45 # =====
46 def movel_commands(server_address, port, tcp, commands):
47     script = ""
48     script += "def program():\n"
49     x, y, z, ax, ay, az = tcp
50     script += "\tset_tcp(p[%5f, %5f, %5f, %5f, %5f])\n" % (x/1000., y/1000., z/1000., ax, ay, az)
51     for i in range(len(commands)):
52         x, y, z, ax, ay, az, speed, radius = commands[i]
53         script += "\tmovel(p[%5f, %5f, %5f, %5f, %5f, %5f], v=%f, r=%f)\n" % (x/1000., y/1000., z/1000., ax, ay, az, speed/1000., radius/1000.)
54         script += "\ttextmsg(\"sending command number %d\")\n" % (i)
55     script += "\tsocket_open(\"%s\", %d)\n" % (server_address, port)
56     script += "\tsocket_send_string(\"c\")\n"
57     script += "\tsocket_close()\n"
58     script += "end\n"
59     script += "program()\n\n"
60     script = script.encode()
61     return script
62
63 # =====
64 def start_extruder(tcp, movel_command, digital_output):
65     script = ""
66     script += "def program():\n"
67     script += "\ttextmsg(\">> Start extruder.\")\n"
68     x, y, z, ax, ay, az = tcp
69     script += "\tset_tcp(p[%5f, %5f, %5f, %5f, %5f])\n" % (x/1000., y/1000., z/1000., ax, ay, az)
70     x, y, z, ax, ay, az, speed, radius = movel_command
71     script += "\tmovel(p[%5f, %5f, %5f, %5f, %5f, %5f], v=%f, r=%f)\n" % (x/1000., y/1000., z/1000., ax, ay, az, speed/1000., radius/1000.)
72     script += "\tset_digital_out(%i, True)\n" % (int(digital_output))
73     script += "end\n"
74     script += "program()\n\n"
75     script = script.encode()
76     return script
77
78 # =====
```




main_direct_send_group_00.py ✕

C:\Users\> nizta > Downloads > main_direct_send_group_00.py > ...

```
main_direct_send_group_00.py X
C:\> Users > nitzta > Downloads > main_direct_send_group_00.py > ...

112
113     commands = commands[1:-1]
114
115     for i in range(len(commands)):
116         script = move_commands(server_address, server_port, tool_angle_axis, [commands[i]])
117         print("Sending commands %d of %d in total." % (i + 1, len(commands)))
118         # send file
119         send_socket.send(script)
120
121         # make server
122         recv_socket = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
123         recv_socket.setsockopt(socket.SOL_SOCKET, socket.SO_REUSEADDR, 1)
124         # Bind the socket to the port
125         recv_socket.bind((server_address, server_port))
126         # Listen for incoming connections
127         recv_socket.listen(1)
128         while True:
129             connection, client_address = recv_socket.accept()
130             print("client_address", client_address)
131             break
132         recv_socket.close()
133
134     if move_filament_loading_pt:
135         script = stop_extruder(tool_angle_axis, last_command, air_pressure_D0)
136         send_socket.send(script)
137         time.sleep(1)
138
139     send_socket.close()
140
141
142 if __name__ == "__main__":
143     main(commands)
144
```